

# ASSEMBLY HINTS AND TIPS

## 6/8 drawer's assembly hints.

(8 drawer all frame pieces in the large box and then x2 part 3 plinths in the smaller package require for main frame)

Please all parts in the same piles before starting and follow all of the picture guides within the instructions.

Part 1 top holes can be either side to secure the top section

All wood has to be flush before inserting the circle cam locks with the arrow pointing towards the fixing screws and then tighten to secure and lock.

### Centre piece side slats

This is the trickiest area for the item, if the circle cam locks are tightened too much to the centre double sided fixing bar it can pull the bar through so the other circle cam lock will not catch it, the best thing to do is to remove the cam locks, place the bar in the centre with the wood slats either side so its flush and even, you can see the bar either side then push the cam locks in with the arrow pointing towards the bar and then tighten slightly alternating slightly between them around a half turn, until they are both caught either side before fully tightening , then they will both catch the wood and will be secure. it's a tricky area but if they are being tightened too much on one end it will pull the bar through too early not given it enough slack at the other end. we also recommend ensuring the wood sections are secure before tightening, it can be a common issue as the bar gets pulled through too early which will not leave it enough slack

Once all drawers are assembled, they will then need to be aligned part 8 and part 9 left and right and cover half the centre column as the drawer faces are different slightly.