



ASSEMBLY INSTRUCTION

DESCRIPTION : 3 DOORS SHOE CABINET

HARDWARE	A	B	C	D	E	F	G	H	I	J	K	L	M
	CB SCREW M3.5X16MM 1X26	CB SCREW M4X38MM 1X6	NAIL 5/8 1X23	D1 D2 D3 3.5 KG MAGNET (1 HOLE) 3 SETS	PVC SHELF SUPPORT 1X16	DOOR SUPPORT SPRING 1X3	MAS R4 1X1 MAS L4 1X2	ROUND PLASTIC LEG (PVC) 1X5	I1 I2 MINIFIX 5654+5546 6 SETS	L-KEY 1X1	QUICKFIT CAP 1X6	HANDLE 5022 (METAL) 1X3	HANDLE SCREW M4X22MM 1X3

