

3/4" DRAPERY ROD INSTALLATION INSTRUCTIONS - 42-120" TRIPLE ROD SET

Care Instructions: Clean with a soft cloth. Do not use abrasive cleaning agents, solvents or polishes.

SET INCLUDES:

(A) X6 (B) X6 (C) X3 (D) X2 (E) X6

(F) X1
Extends 42-120"

(G) X2
Extends 42-120"

Note: Caps (E) are pre-assembles on the smaller diam. telescoping rods.

YOU WILL NEED:

1/4" dia.

1

Extends 42-120"

Before installation, measure windows to determine appropriate drapery rod length.

2

Remove screws to separate the bracket (C). Use bottom section of bracket (C) as a guide to mark location for mounting screws (A).

3

Drywall

Drill pilot holes into wall with 1/4" drill bit (not included). Insert wall anchors (B) and attach bracket (C) using mounting screws (A). Wall anchors may not be necessary if drilling into studs.

4

Repeat steps 2-3 for additional brackets. Use level if necessary.

5

BACK AND MIDDLE RODS

(G) → **For 42-80"**
Use 2 telescopic rod sections (1 larger diam. and 1 smaller diam.).

(G) → **For 80-120"**
Use 3 telescopic rod sections. Extend the smaller diam. rod that is nestled in the larger diam. rod. Then insert the smaller diam. center rod into the second larger diam. rod section.

6

Place drapery panels (not included) onto drapery rod and extend to desired length. Hang rod in back position on brackets. Repeat for middle rod and hang in middle position on brackets. Reassemble the brackets (C), adjusting to desired depth. Tighten screws to secure.