

Installation Instructions

These instructions will cover the products listed below, all of which are available at Wayfair:

Small/Med. Animal Barrier

32" in length, 8" in depth with 2" spike spacing



(Suggested for preventative use)

Large Animal Barrier

32" in length, 10" in depth with 2.5" spike spacing



(Suggested for preventative use)

XL Animal Barrier

24" in length, 15" in depth with 1.5" spike spacing



(Suggested for immediate fix or preventative use)

To secure your fence, keep pets in, and predators out:

On **chain link fences**, place the spikes over the bottom wire of your fence or by interlocking the unit with the fence. Stop driving when the top lateral wire is even with bottom of fence.

On a **wooden privacy fences**, install from inside of fence (same side of post) or outside of fence, driving unit straight down. Stop driving when the top lateral wire is even with the bottom of the fence. If wood is being chewed, install from inside of fence straight into ground and attach top lateral wire with a staple.

The previous instructions can be applied to **Wrought Iron, Vinyl, and Decorative** fencing.

For best results, use a hammer and gloves while hitting each spike evenly. If one or more spikes comes in contact with a rock, remove the spike with bolt cutters or bend it

For a more visual perspective of the installation process, please visit our [website](#)

An extra Stop The Dig Tip:

For already established digging areas or for "favorite" spots, please look at the **XL model** for the immediate correction. While the 2" and 2.5" spacing models are more for preventive use, the **XL model** is the "I need this stopped right now" model. Use the 2" and 2.5" models when the ground under the fence is still intact or close to the bottom of the fence.

