

**1,Clean and dry the stairs**



**2,Peel off backing adhesive film**



**3,Place on stairs Press firmly**



**Easy remove,no residue left**

