

Wallpaper Hanging Instructions

Unless Manufacturer's Instructions Specify Alternate Method

WALL PREPARATION:

All walls should be clean and smooth. Plaster walls and ceiling should be primed with an oil base primer and should be sized. Latex, semigloss or enamel walls should be sanded and primed with an oil base primer. Plasterboard walls should be sealed and sized. We recommend the use of lining paper on all walls. We do not recommend the use of pre-sized adhesives for hanging Brunschwig & Fils, Inc wallcovering.

WALLPAPERS

All papers should be hung with a good quality wheat paste of a non-staining cellulose paste. Adhesive left on the surface of the paper may cause flaking.

VINYL PAPERS

For hanging we recommend a good grade of pre-mixed vinyl adhesive.

TEMPERA PAPERS (WATERCOLORS)

We recommend a cellulose paste. This paper is not washable and the utmost handling care is required so as not to get paste or wash water on face of paper. For best results, we recommend water/soil resistant treatment.

FOILS AND METALLICS

Vinyl adhesive is recommended. To avoid creasing and cracking, dry trim and apply adhesive to the wall. Sweeping the paper with a down and outward motion, to help prevent bubbling and wrinkling.

BURLAP, TEXTURED OR CRAFT PAPERS

Pre-mixed vinyl adhesive is recommended.

GRASSCLOTH

Grasscloth coverings are handcrafted of natural materials. Full hanging instructions are included with every roll, and all recommendations should be followed. We recommend that a top quality, non-staining adhesive be used when hanging these products or an adhesive that is specially made for use with delicate wallcoverings such as Grasscloth, silks and fabrics. Care must be taken to not over-wet. Vacuum cleaning is recommended.