

**1. First take out the glue in each round hole drop special glue, be sure to evenly not too full.**



**2. Take out the support, insert the support into the round hole of the chassis, do not plug the stick, use the rotary square. Type insert, this is relatively easy oh!**



**3. Once the base is secured. Put the top bamboo frame, align the round hole slightly turn down the bracket will be stuffed into**

