

## **Installation method of perforation-free shower curtain rod**

1. First take out the pipe fitting, hold the inner tube of shower curtain rod with one hand and the outer tube with the other, turn counterclockwise to unlock the lock, and then insert the pipe fitting into the elbow.
2. The installation height is recommended to be based on the shower curtain. Keep the shower curtain 1-2cm off the ground. The actual height is determined according to your own needs.
3. Wipe the flange base clean, take out the nail free glue, and evenly apply the nail free glue on the flange base, as shown in the figure.
4. Stick the installation height mark on the wall, as shown in the picture, with flange screw downward, press hard for about 10 seconds, and fix with auxiliary paste. The setting time of nail free glue is 3-5 days in spring and summer, and 5-7 days in autumn and winter.
5. Adjust the fitting to the appropriate size, lock clockwise, insert both ends into the wall flange, install the flange screw tight, keep the shower curtain rod perpendicular to the wall, do not tighten too hard.

### **Points for attention:**

Do not remove the black plug at the end of the straight rod!

Do not lock the fixed straight rod too hard!

Apply flange crystal board glue evenly!