

Attaching CH Sliders



1. Remove the finial from the rod
2. Remove the plastic insert in the end of the rod
3. Slide in new sliders with clips
4. Re-attach plastic insert and finials