

ASSEMBLY INSTRUCTIONS:

※VERY IMPORTANT

PLEASE READ THOROUGHLY MAKE SURE YOU PROPERLY ALIGN POLES BEFORE SCREWING THEM TOGETHER TO AVOID DAMAGING CONNECTION THREADS. NOT ADHERING TO THIS PROCEDURE MAY VOID YOUR WARRANTY

1. CAREFULLY UNPACK AND PLACE ALL PARTS ON A FLAT SURFACE AND LINE THEM UP AS PER THE SKETCH
2. SCREW TUBE (B), AND BEND TUBE (C) INTO BASE (A) IN TURN, PULL THE WIRE OUT FROM BOTTOM OF THE BASE (A)
3. SCREW HANDLE (D) INTO BEND TUBE (F) AND TWIST SCREW (E)
4. ATTACH THE SHADE (H) ON THE SOCKET (G) AND SECURE SOCKET RING (I)
5. INSERT BULB (J) (NOT INCLUDED) INTO SOCKET (G)
6. INSERT THE POLARIZED PLUG INTO WALL OUTLET, TURN ON THE SWITCH AND ENJOY YOUR NEW LAMP

Use A Type 100W (Maximum) (bulb not included)

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE

THE RISK OF ELECTRIC SHOCK, THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY (A) BASE

IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH

AN EXTENSION CORD UNLESS PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THIS PLUG.

ATTENTION:

POUR PRÉVENIR LES CHOCS ÉLECTRIQUES NE PAS UTILISER CETTE FICHE POLARISÉE AVEC UN PROLONGATEUR, UNE PRISE DE COURANT OU UNE AUTRE SORTIE DE COURANT, SAUF SI LES LAMES PEUVENT ÊTRE INSÉRÉES À FOND SANS EN LAISSER AUCUNE PARTIE À DÉCOUVERT

※ PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.

※ SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

