

5/8" DRAPERY ROD INSTALLATION INSTRUCTIONS - 48-86" ROD SET

Care Instructions: Clean with a soft cloth. Do not use abrasive cleaning agents, solvents or polishes.

SET INCLUDES:

(A) (B) (C) (D) (E) (F)

X6 X6 X3 X1 X1 Extends 48-86" X1

Note: Finial (D w/ smaller post) fits to the smaller diam. rod - Finial (E w/ larger post) fits to the larger diam. rod.

YOU WILL NEED:

1/4" dia.

1

Extends 48-86"

Before installation, measure windows to determine appropriate drapery rod length.

2

Use bracket (C) as a guide to mark location for mounting screws (A).

3

Drywall

Drill pilot holes into wall with 1/4" drill bit (not included). Insert wall anchors (B) and attach bracket (C) using mounting screws (A). Wall anchors may not be necessary if drilling into studs.

4

Repeat steps 2-3 for additional brackets. Use level if necessary.

5

Extend telescoping rod (E) slightly.

6

Place drapery panels (not included) onto drapery rod and extend to desired length. Hang rod on brackets. Insert finials (D & E) into ends of rod and tighten set screws on brackets (C).