

# Vanity Art Bathtub Installation Guidelines

Our bathtubs come with a pop-up drain already installed and overflow already integrated to the drain. The preferred method would be to attach the bottom of the drain to your floor drain with rigid plumbing. The flexible drain hose is an optional piece only to be used if you have no access underneath the bathtub. One end screws onto the bottom of the bathtub drain and the other end to your floor drain using a transition piece, compression fitting, or clamping fitting you can get from any Home Improvement store. The flexible drain hose is 36" long and can be cut down to the desired length if there are any issues with slow draining. It is recommended that you use silicone on the leveling feet and/or base of the tub for added stability, especially when not using rigid plumbing. Have a great day!