INSTALLATION INSTRUCTIONS



Preparation
Unpack all parts and check the hardware bag (screws and protective pads).
Tip: Apply the black protective pads to the bottom of the metal bases to prevent floor scratches.
Step 1: Place the Tabletop Upside Down
Carefully lay the tabletop upside down on a soft, clean surface (like a blanket or the packaging foam) to protect the top surface and avoid scratches.
Step 2: Position the Bases
Take the two triangle metal bases and place them onto the bottom of the tabletop.
Important: Make sure the triangle faces inward (towards each other), exactly as shown in the photo.
Align the holes on the metal base with the corresponding positions on the bottom of the tabletop as shown on both sides of the picture.
Step 3: Insert and Tighten the Screws
Insert the screws into the aligned holes.
Tighten them securely using a screwdriver.
(Since these are self-tapping screws, you can use a manual screwdriver or an electric drill with a suitable torque setting. Be careful not to over-tighten and strip the wood.)
Step 4: Flip Over
Once all screws are tight and the bases are firmly attached, carefully flip the entire table upright with the help of another person.





