

# LESS CARE

UNDERLAYMENT

**LCU1-200**

Model Number

**200 Sq Ft / Roll**

**3 mm**

Underlayment Thickness

- 3-in-1 Moisture Control
- Conceals Minor Sub-Floor Defect
- Reduces Noise Level
- Lifetime Limited Warranty

For Use Under:

- All Laminate
- All Engineered
- All Wood Flooring



[www.LessCare.com](http://www.LessCare.com)

Made in China

# LESS LARE

## UNDERLAYMENT

### Installation Instructions:

1. Clean and level sub-floor. Be sure the sub-floor is dry
2. Roll out underlayment with the moisture barrier film facing down to the sub-floor.
3. Join seams of the underlayment with tape
4. Install the flooring according to the flooring manufacturer's installation instructions.

