

# ASSEMBLY INSTRUCTIONS

1. CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE AND LAY THEM UP AS PER THE SKETCH.
2. SCREW SOCKET ASSEMBLY (D) CLOCKWISE INTO LAMP BODY (E) TO TIGHTEN .
3. SCREW THE THREADED ROD(C) INTO LAMP SOCKET(D) TO TIGHTEN. PLACE THE SHADE(B) INTO THE THREADED ROD(C). THEN TIGHT THE FINIAL (A).
4. INSERT THE POWER PLUG INTO PLUG SEAT TO USE

**Use MAX 2\*60 Wattage type A bulb (bulb not included)**

## IMPORTANT SAFETY INSTRUCTIONS:

**SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

