

ASSEMBLY INSTRUCTION QUEEN BED

Page : 1 OF 1


Before you begin, please read Assembly Instruction carefully and recognized the part and hardware. Then follow them step by step.

ASSEMBLY TIPS:

Remove hardware from box and sort by size.

Please check to see that all hardware and part are present prior start of assembly.

HEADBOARD



HARDWARE PART 1

NO	HARDWARE DESCRIPTION	QTY
A.	Wood Dowel M12 x 50mm 	2PCS
B.	Wood Botton M15 x 9mm 	2PCS
C.	JCBC Bolt M6 x 50mm 	2PCS
D.	JCBC Bolt M6 x 35mm 	4PCS
E.	Allen Key 	1PC
Screw Driver Not Provide !!!		

TIPS:


Attach & tighten the Headboard Leg (R&L) to the Headboard with Hardware Part 1.

ASSEMBLY INSTRUCTION QUEEN BED


Page : 1 OF 1

Before you begin, please read Assembly Instruction carefully and recognized the part and hardware. Then follow them step by step.

STEP 1.





STEP 2.



TIPS : REPEAT STEP 1 TO JOINT FOOTBOARD.

STEP 3.



HARDWARE PART 2

NO	HARDWARE DESCRIPTION	QTY
F.	Chipboard Screw M4 x 32mm	6PCS
G.	JCBC Bolt M6 x 40mm	3PCS
H.	Adjuster Screw M6 x 24mm	3PCS

Screw Driver Not Provide !!

COMPLETE SET

