

Waste System Installation Instructions

Edge Series Bottom Mount Waste Systems

- 1) Locate Waste System in cabinet opening & determine final location & screw through the installation brackets into the floor of the cabinet (screws not included).
- 2) Locate door onto front of Waste System & fasten by screwing through door mounting brackets into door styles/uprights (screws not included).
- 3) For final placement Waste System can be adjusted left or right due to slotted holes in installation brackets. Set screws in the door mounting brackets allow for tilt control if needed.

Please note: on our new the stainless 2 qt canisters are originally placed to the right of the waste bins. If the consumer prefers the canisters on the left, the top can easily be reconfigured by removing the 4 screws that fasten the top, rotate appropriately and then refasten with the 4 screws.

Top Mount Waste Systems

- 1) Separate cabinet member of drawer slide from drawer member of the slide & determine final location of Waste System & screw cabinet members to cabinet (screws not included). On framed cabinets you will need to block out cabinet wall or use rear mounting sockets (provided).
- 2) Insert Waste System into cabinet members of slides.
- 3) Place cabinet door onto front of Waste System & find final location. Screw through Waste System front into door stiles/uprights (screws not included).