

Finial Assembly Instructions

Dalvento finials come with a **finial figure** and a **black steel assembly rod**.

If you are installing on a roof, you will need a roof mount.

We recommend the Dalvento Small Steel Roof Mount (Item # 901S) or Dalvento Aluminum Roof Mount (Item # 904) for all 24" (Small) and 36" (Medium) sized finials.

We suggest the Dalvento Large Steel Roof Mount (item # 901L) for all 48" (Large) finials.

All 12" (Mini) Dalvento finials come complete with a roof mount so no additional hardware is needed.

To install your finial onto a roof:

1. Position roof mount in the desired place on roof and affix mount with screws provided.

Tip: You can pre-drill the screw holes and then apply some silicone caulk to the holes before screwing mount to roof. This will further help protect against any leakage.

2. Insert finial assembly rod into roof mount and attach by tightening screws on side of roof mount.

3. Slide finial onto assembly rod. That's it- your finial is now installed and ready to be enjoyed!

Note: The threaded tips at each end of the assembly rod are only there to connect to additional assembly rods if necessary. Additional rods may be required for the extra length needed to reach a mount within a roofline or cupola. The threads are *not* there to screw into the finial or into a roof mount- they are only there for additional rod lengths if necessary.

The finial figure will rest on the assembly rod with no additional securing needed. However, if you are concerned about the finial not being firmly affixed to the assembly rod, you can use an adhesive like silicone caulk (or another adhesive recommended by your roofer). Apply silicone caulk inside finial shaft and also on assembly rod. Slide finial onto assembly rod. Adhesive will set and finial will be premanently attached.