

installationinstructions:

SHUTTER HOLDBACK INSTALL

SAFETY INSTRUCTIONS

Make sure to use the correct tools recommended.

Wear safety goggles.

Follow fixture, power tools, and paint manufacturers' instructions and users manuals.

Use common sense and follow good construction practices.

TOOL & MATERIAL CHECKLIST

- | | |
|---|--|
| <input type="checkbox"/> Electric drill | <input type="checkbox"/> Socket wrench |
| <input type="checkbox"/> 3/8" drill bit | <input type="checkbox"/> Pencil |
| <input type="checkbox"/> Screw driver | |

IMPORTANT INFO

- Use appropriate drill bit for siding / install surface type.
- SteelTek hardware is manufactured from 304 stainless steel with powder coat black finish
- Additional instructions available for hinges, pintels, and other hardware components.

INSTALL INSTRUCTIONS:

Figure 1) If using S hooks only:

1. Mark location where lag bolt will be attached to structure.
2. Pre-drill into structure for 3/8" lag bolt
3. Slide S hook and washer over lag bolt
4. Fasten lag bolt to structure.

Figure 2) If using hold back shutter supports:

1. Follow same instructions as figure 1.
2. After sliding S hook and washer over lag bolt, slide shutter holdback support over lag bolt.
3. Fasten lag bolt to structure.
4. Use set screws to tighten shutter holdbak support to lag bolt.

EXAMPLE DIAGRAM:

FIGURE 1



FIGURE 2A



FIGURE 2B

