

**How to Install:**

1. Tear off the protective film on the four sides.
2. Fasten the rubber ring to the panel.
3. Install glasses holder accessories, empty tubes, and screw caps.
4. Place the ball ring with the protrusion facing upward in the bottom groove.
5. Pass the long rod screw through any round plate and connect it to the round plate through the hole in the base.
6. Screw the nut on the bottom of the base to fix.
7. Insert the installed panel into the bottom slot.
8. Install the remaining panels.