



1. install one side with screw,the aluminum frame with hole is in the first and fourth.



2.canopy plug into the frame



3.canopy plug into the frame



4.install the other side with screw,installation the 4 pcs aluminum



5.finished install the canopy



6.install the air bolt pole,use the screw to fixed the fabric and aluminum(the have a hole in the fabric and aluminum)



7.finished install one side of air bolt pole



8.one person pull the air bolt pole(With great force),the other person to fixed the air bolt pole other side.