



Cabinet Door \*1

Left Bracket

Right Bracket

Back Panel\*1



Short Laminate\*4



Top/Bottom Panel\*2



Hinges\*2



Handle\*1



Hexagonal Wrench

Short Phillips  
Screws



Flat Head  
Phillips Screws



Hexagonal  
Screws



Note that the base plate and bracket grooves are uniformly oriented

Note that the side brackets do not need to be screwed too tightly

1. We first connect the two sides of the bracket and the base plate with hexagonal screws to fix

2. Then fix the long laminate from the second hole

4. Install the laminate in turn (as shown above).

Finally install the cabinet door (installation complete)

5. Fix the double-sided groove strips first and then insert the back plate.

6. Fasten the top plate after the top screws and then tighten all the screws on both sides

Drawings for the single-door 6-layer installation of other layers of styles of installation methods as the same number of layers are not the same, the laminate will also be different, specific reference options map