

<p>position A ① upper metal ring 1pcs hole A ② screw ③ T shape profile 10pcs</p>	<p>⑧ light fixture 1pcs ⑨ crystal piece 10pcs</p>	<p>⑤ ① ⑥ ④ ⑤ hole A position A hole B position B</p> <p>position A and hole A of ring ① should face to position B and hole B of ring ④ at the same time.</p>
<p>position B hole B bottom metal ring 1pcs</p>	<p>⑩ chain 1pcs ⑪ bracket:1pcs ⑫ canopy:1pcs ⑬ metal ring:1pcs</p>	<p>1. Install upper metal ring ① and bottom metal ring ④ together with tube ⑥ and screw ⑤.</p>
<p>⑤ screw ⑥ connected tube 4pcs ⑦ hanging tube 1pcs</p>	<p>X 1pcs X 3pcs X 3pcs X 3pcs</p>	<p>⑧ vertical view ⑨ ① ② ③ ④ insert the crystal piece ⑨ from the side.</p> <p>If the crystal piece loosen after insert in the profile, take out and pull down the position A of ring ① a little bit and insert the crystal piece again.</p> <p>2. Adjust the light arm to suitable position like picture shown. 3. Let the wire of light fixture ⑧ go through the metal frame ① and hanging tube ⑦, rotate tube ⑦ to install all parts together.</p> <p>4. Loosen but don't remove out the screw ②, insert the crystal piece ⑨ from the side, rotate to fasten the screw ②.</p>
<p>⑩ ⑦</p> <p>5. Install the chain ⑩ to the light fixture ⑦, let the wire go through the chain ⑩.</p>	<p>⑪ ⑫ ⑬ ⑭ ⑮ ⑯ ⑰</p> <p>Please operate with gloves to avoid leaving stains on the lampshade.</p> <p>6. Install the bracket ⑪ to the ceiling junction box with screw ⑭ . 7. Let the chain ⑩ and wire go through the ring ⑬, canopy ⑫ and bracket ⑪ , hang the chain ⑩ to the bracket ⑪ . 8. Connect the wire to your home line with cap connector ⑮ . 9. Install the canopy ⑫ to the bracket ⑪ with ring ⑬ . 10. Install the bulb ⑰ .</p>	
<p>Please read carefully before installation!!! Note : Please make sure that the electricity is powered off during installation ! Only a professional electrician should install this kind of product !</p>		