

installation instructions:

CROWN MOULDING

SAFETY INSTRUCTIONS

Make sure to use the correct tools recommended.

Wear safety goggles.

Follow fixture, power tools, and paint manufacturers' instructions and users manuals.

Use common sense and follow good construction practices.

TOOL & MATERIAL CHECKLIST

- construction adhesive
- caul k
- caul k ng gun
- fin sh ng na s
- m ter saw
- pa nt
- cha k ne box & penc

IMPORTANT INFO

- It s h gh y recommended that you pa nt or fin sh mou d ng w th 100% acry c atex pa nt before nsta at on.
- Once nsta ed, you can app y any necessary touchup pa nt or fin sh.
- P ace mou d ng n room 2 to 3 days pr to nsta at on. Th s a ows the mou d ng to adjust to the temperature of the room.
- C ean nsta at on su face and back of mou d ng of a d rt and dust w th a c ean c oth or sponge. Make sure that the surface and the back of the mou d ng are comp ete y dry before attempt ng nsta at on.

INSTALL INSTRUCTIONS:

Crown Moulding Installation

- 1 Prep un versa corners and mou d ng by tr mm ng and match ng up deta s as necessary
- 2 App y a cont nuous 1/2 bead of construct on adhes ve a ong the top and back of mou d ng engths and un versa corners Adhes ve shou d be used to fi any gaps Press mou d ng nto p ace F n sh ng na s shou d be used to secure mou d ng
- 3 App y cau k n rema n ng gaps and smooth w th finger or putty kn fe
- 4 Touchup mou d ng as needed

Mitering Corners

- 1 P ace mou d ng n the m ter box w th the wa s de aga nst the s de of the m ter box oppos te you and the ce ng touch ng s de aga nst the bottom of the box
- 2 Cut m ters and butt jo ns pr to nsta at on

EXAMPLE DIAGRAM:

