



## ASSEMBLY INSTRUCTIONS

1. Carefully unpack and identify all parts referring to illustration for parts identification.
2. Turn the power to the installation point OFF.
3. Assemble the rods (C, D) together and thread the bottom end into the coupling on socket (E) until snug. Thread the top end of the rods into the canopy (A).
4. Place the canopy (A) over the crossbar and allow the mounting screws to go through the canopy (A), securing with the round nuts (B).
5. Install the shade (F) onto the socket (E) and secure with the socket ring (G)
6. Install the bulb (not included) into the socket (E).
7. Refer to the additional installation instructions included with the product for wiring and installation.
8. Restore power to the installation point and retain this sheet for future reference.