



GLASS KIT INSTALLATION INSTRUCTIONS

For those who have purchased a Kimberly Bay Glass Kit for your new or existing door, the following is the easiest step-by-step instruction on how to insert your kit.

1. If you have installed your screen as per the recommendations, it should look like the example in 'Picture 1' below. Use a Robertson #1 screwdriver to remove the corner screws and loosen the side clips just enough so that they will rotate to allow the screen to be removed.
2. Store your screen in a secure place where it won't get damaged, so that you may reinstall it when the weather becomes appropriate for screened airflow.
3. Replace the screen with the 3MM tempered glass storm kit and using the same Robertson #1 screwdriver, attach the provided 8 clips using the screws that are also provided. Refer to picture 2 for approximate locations for the addition of the new clips/screws.
4. Tighten the clips to ensure the glass is securely held in place.
5. When reinserting the screen, loosen the screws on the screen tabs, turn them, and lift the 3mm tempered glass storm kit out and install the screen. Turn the Screen tabs to the hold position to secure the screen. Follow these easy instructions and continue enjoying your Kimberly Bay wood screen/storm door.



Picture 1



Picture 2

