

210\*145mm

2017.9.24

### Shoe Cabinet Installation Instructions







Before installing using the product, please read these instructions carefully before assembling the product.  
 Use for home bedroom private room, etc.  
 Material: steel, plastic fittings, Oxford cloth or non-woven fabrics  
 Toxic substances: None

**Precautions:**

1. Do not touch the cut surface of the steel pipe
2. Make sure that the various parts of the accessories are complete
3. Be sure to follow the installation sequence assembly instructions

**list:**

Weather colder regions Note: Soak interface with warm water for a few minutes

ITEM	QTY	IMAGE
Short tube	40	
Middle tube	22	
Long tube	20	
Tee joint	36	
Right angle	4	
Tee Feet	4	
Net cloth	10	