

TOOL-FREE installation

1 Dry surface



2 Remove film



3 Stick & Wait for 24h



4 Hang the caddy



Marble



Steel



Tiles



Glass



Mirror



Painted Wall



Wallpaper



Rough surface



Rustic tile



Mosaic tile