## PENDANT FIXTURE INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them a later date.

## CAUTION

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

## **GENERAL**

All electrical connections must be in accordance with local and National Electrical Code(N.E.C) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician. Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

## **ASSEMBLY AND INSTALLATION**

- Connect the Pipe (1),(2),(3),(4), (5) together with the fixture. Then screw with the Swivel.
- Attach two Screws-1 outward through the CROSS BAR, spin the Hex nut to the Screw-1, then attach the CROSS BAR(6) to the OUTLET BOX by the two MOUNTING SCREWS.
- Screw the butterfly nut, key washer and metal washer from the threaded tube.
- Måke wire connections:
  - -Twist together the white wire from the fixture with the white wire from outlet box. Cover with wire connector
  - --Twist together the black wire from the fixture with the black wire from outlet box. Cover with wire connector
  - --Loop the GROUND WIRE to CROSS BAR with a GREEN SCREW.
- Place the CANOPY against the OUTLET BOX by screwing the Ball
- Attach the SHADE( not included) onto the SOCKET, screwe SOCKET RING tightly.
- Install bulbs (Please do not exceed the maximum capacity which is recommended on the sockets).

