



TAHITIAN PALM THATCH

Installation Instructions

1. In order to achieve full coverage on your roofing structure, the panels must overlap each other at least 20 inches on center.
2. Tahitian palm thatch is easily installed by stapling. Begin by measuring and marking the desired area on which you want to apply the thatch.
3. Cut your thatch as needed with sharp, heavy-duty scissors.
4. Begin installation at the bottom of the roof and work horizontally. Using a staple gun, lay thatch out on previously marked measurements.
5. Overlap the panels approximately 20 inches on center and work up to the ridge.
6. To cover the hips and ridge of roof structure properly, you will have to measure and cut smaller portions of the thatch and then apply.