



1. First fix the base on the frame, as shown in the figure, L shape on the left, long strip on the right



2. Finally, the base is connected to the bottom of the rock plate with self-tapping screws