

INSTALLATION INSTRUCTION



1. Fix the housing into the hole



2. Push the trim into the hole



3. Screw the bulb into the socket



4. The installation is finished