

1" DRAPERY ROD INSTALLATION INSTRUCTIONS - 18-36" ROD SET

Care Instructions: Clean with a soft cloth. Do not use abrasive cleaning agents, solvents or polishes.

SET INCLUDES:

(A)	(B)	(C)	(D)	(E)	(F)
X4	X4	X2	X1	X1	Extends 18-36" X1

Note: Cap (D) fits to the smaller diameter rod - Cap (E) fits to the larger diameter rod.

YOU WILL NEED:

1/4" dia.

1

Extends 18-36"

Before installation, measure windows to determine appropriate drapery rod length.

2

Wall Mount

Ceiling Mount

Use bracket (C) as a guide to mark location for mounting screws (A). Drill pilot holes into wall with 1/4" drill bit (not included).

3

Drywall

Joist

Ceiling

Insert wall anchors (B) into pilot holes and attach bracket (C) using mounting screws (A). Wall anchors may not be necessary if drilling into studs. For ceiling mount installation, we recommend mounting to a ceiling joist or to consult your local hardware store for the best hardware for your application.

4

Repeat steps 2-3 for additional bracket. Use level if necessary.

5

Extend telescoping rod (F) slightly.

6

Place drapery panels (not included) onto drapery rod and extend to desired length. Feed rod through the rings on brackets (C). Insert finials (D & E) into ends of rod and tighten set screws on brackets (C).