

R201

Instructions:

1. Press cap onto air gap body.

Instrucciones:

1. Presione tapa sobre el cuerpo hueco de aire.

Care Instructions:

Do not use plumbers putty during installations. Use only clear silicones. Do not clean with abrasive cleaner, as this will void all warranties. Use only water and mild soaps. Use a high grade carnauba wax like Turtle wax for clear coat car finishes or Meguiar's to maintain luster.

Instrucciones de Cuidado:

No usar masilla de plomerodurante la instalación. Usar únicamente siliconatransparente. No limpiar con productos abrasivos, esto cancelará toda garantía. Usar únicamente agua y detergente. Para conservar el lustre aplicar una vez por mes cera de alta calidad para lustre de automóviles.