Outdoor Loveseat

Your furniture requires assembly prior to use. It is important that you read the entire assembly instructions to become familiar with the unit before you set up this product.

Safety Warning and Precautions

WARNING: When setting up your furniture, basic precautions should always be followed to reduce risk of personal injury and damage to the product.

Read all instructions before assembly and usage this product.

1. Select ideal location. Set out all parts on a clear and level surface prior to assembly. Ideally, the furniture should be set up in the desired location to avoid moving it after assembly.

2. Use caution. During all the processes of assembling, especially when lifting heavy or large parts, pay attention to safety.

3. Tools and Assistance. An adjustable spanner is required for assembly. It is recommended 2 people assist with assembly.

4. Check all parts before assembling, ensure you have all parts detailed in the parts list on Page 2.

5. Refer to assembly diagram. During assembly, refer to the assembly instructions on following pages.

6. Caution. Keep children away from work area during assembly. Do not allow children to handle parts or tools while assembling.



FITTINGS IDENTIFICATION

Part # Description:	M645 Screw M6*45	M625 Screw M6*25	X Gasket	Z Allen Wrench
Description				·
Figure:	M6*45	M6*25	Ø12*Ø6.5*1.0	
Qty:	8PCS	2PCS	10PCS	1PCS



CAUTION: Pre-assemble all the bolts loosely but do not fully turn the bolts into their holes until all bolts are inserted in their holes.

\⇒5Ū



STEP1





Steps:

1. Attach the Back Frame (Part A) to the Seat Panel (Part B) with Screw M6*45 (Part M645) and Gasket(Part X) by using Allen Wrench (Part Z), Install the Both side holes first, then install the Scerw M6*25(Part M625) and gasket (Part X) to the Middel hole by using Allen Wrench(Part Z2).

Tighten all screws. Your loveseat is ready to use. (Note: Pre-assemble all the bolts loosely but do not fully turn the bolts into their holes until all bolts are inserted in their holes.) Periodically check and make sure that all screws are fully tightened.