

INSTALLATION AND SAFETY INSTRUCTIONS

FOR YOUR SAFETY

WARNING: BE SURE THE ELECTRICITY TO THE WIRES YOU ARE WORKING ON IS SHUT OFF; EITHER THE FUSE IS REMOVED OR THE CIRCUIT BREAKER IS SHUT OFF.

GENERAL

You don't need special tools to install this fixture.

Be sure to follow the steps in the order given. Under no circumstances should a fixture be hung on house electrical wires, nor should a swag type fixture be installed on a ceiling, which contains a radiant type heating system. Read instructions carefully. If you are unclear as to how to proceed, consult a qualified electrician.

NOTE: Proper wiring is essential for the safe operation of this fixture.

FIXTURE ASSEMBLY

Carefully removed the fixture from the carton and check that all parts are included as shown in figure. Be careful not to misplace any of the screws or parts, which are needed to install this fixture.

INSTALLATION

STEP 1: Fix glass(S)(2PCS) on the longer side of lamp body by using the pins(R). Fix glass(T)(2PCS) on the shorter side of lamp body by using the pins(R).

STEP 2: Unscrew two ball nuts(M), and then remove the mounting plate(D) from the canopy(K).

STEP 3: Rod connections:

Thread the fixture wire(Q) from the fixture through the rods(P,O,N) onto fixture using the threaded pipes.

Note: Use fewer rods if shorter length is desired.

STEP 4: Thread the fixture wire through the canopy kit(K), and then secure the rod assembly to the set nipple(L) of the canopy kit as shown in diagram.

STEP 5: Place the mounting plate(D) to the outlet box(A) and mark the target on the wall surface from the set hole for drilling two holes. Remove the mounting plate from the outlet box. Thread the anchors(B) into the holes, then attach the mounting plate to the outlet box by using two mounting screws(F). Secure the dry wall screws(E) through the set holes into the anchors.(B).

STEP 6: Pull out the source wires from the outlet box(A).

Make wire connections using wire nuts(G) as follow:

- Connect the smooth-coated wire(marked) from the fixture to the black wire from the power source.
- Connect the ribbed-coated wire(unmarked) from the fixture to the white wire from the power source.
- Attach the fixture grounding wire to the mounting bracket with the green grounding screw(C), and then connect it to the house grounding wire with wire nut(G).

Carefully put the wires back into the outlet box.

STEP 7: Attach the canopy to the mounting plate by inserting two screws, and then secure it with two ball nuts(M).

STEP 8: Install bulbs(U)(Included vintage bulb 4*60W).

See relamping label at socket area or packaging for maximum allowed wattage.

CLEANING

To clean, wipe fixture with a soft and dry cloth. Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.

Line art shown may not exactly match the fixture enclosed. However, the installations do apply to this fixture.

