

# HOW TO GUIDE **INSTALL**

## STEPS TO INSTALL:

- 1) Make sure to clean the surface of the vanity, backsplash, and sidesplash.
- 2) Apply construction adhesive to the backside of the backsplash with a caulk gun.
- 3) Apply a thin line of silicone along the edge of the vanity top, where the backsplash will sit.
- 4) Set the backsplash in place. Press the front and top to ensure good adhesion.
- 5) If applicable, apply a thine of silicone along the front edge of the backsplash, where the sidesplash will touch the front side of the backsplash.
- 6) If applicable, set each sidesplash in place and press for good adhesion.
- 7) Once set, apply silicone where the backsplash (or sidesplash) and countertop meet.
- 8) Smooth the caulk line with a caulk tool.



## SUPPLIES NEEDED TO INSTALL A BACKSPASH

- Caulk Gun
- Construction Adhesive
- Waterproof Clear Silicone Caulk
- Caulk Tool (optional)
- Pre-Cut Backsplash and/or Sidesplash