

# *Instruction Label*

## For Stair Tread Kit



### **STAIR TREAD INSTALLATION KIT**

#### INSTRUCTIONS:

**Contents:** (1) 6"x28' roll of double faced adhesive padding, each roll will yield approximately (13) pcs.

**Tools Needed:** Scissors

**Step-1:** unroll padding and cut pieces approximately 26" long ( if used on ovals trim excess in corners)

**Step-2:** clean and dry stair surface before installing.

**Step-3:** remove clear plastic and center piece of padding on stair with adhesive side up. Press firmly until padding is secure

**Step-4:** remove adhesive backing, center stair tread on padding and press firmly until stair tread is secure.

**Step-5:** repeat these steps for all other stair treads.

||| *Like us on Facebook!*