



## ASSEMBLY INSTRUCTION

1. Unscrew the NUT ( D ) ,remove the WASHER ( C ) , put the PIPE ( B ) insert the BASE ( A ),use the SPANNER ( E ) screw the WASHER and NUT.
2. Attach EVA ( F ) to the bottom of the base.
3. Link up the connector ( H ),unscrew the Fixed Handle ( I ) , then put the 3-ARM PIPE ( G ) insert the PIPE ( B ) , screw the Fixed Handle ( I ) .
4. Insert one end of the dual DC headwire into the DC head seat 1 , insert the other end of the dual DC headwire into the DC head . seat 2.

### \*CAUTION:

WHEN CONNECTING THE 3-ARM PIPE TO THE STEEL PIPE,MAKE SURE THE NOTCHES MATCH ON BOTH ENDS.MISMATCH OF THE NOTCHES CAN CAUSE SERIOUS.DAMAGE TO THE EQUIPMENT AND POSSIBLE FIRE HAZARD.