

Base with Drawer

Getting Ready

- Begin by laying out all parts on a clean, protected surface.
- Gather the tools and materials needed for assembly:
 - Wood glue
 - Rubber mallet
 - Screwdriver
 - Nail gun

Cabinet Assembly

- Screw the side panel brackets into the predrilled upper and lower holes on the face frame.
- Apply wood glue into the grooves on both sides and along the bottom of the face frame.
- Insert the first side panel into the groove and secure it to the side panel brackets.
- Repeat with the second side panel.
- Slide the bottom panel into the grooves in the side panels and face frame.
- Slide the back panel into the grooves in the side panels.
- Attach the corner brackets to the top of the side panels, face frame, and back panel.
- Secure the drawer support bracket to the back panel.
- Attach the drawer slides to the drawer support bracket and secure them to the side panels.

Door Assembly

- Insert the hinges into the pre-bored holes in the door.
- Secure the hinges with the provided screws.
- Align the hinges with the face frame and attach the door to the cabinet.

Drawer Assembly

- Click the drawer sides into the grooves on the drawer front.
- Slide the drawer bottom into the grooves in the drawer sides and drawer front.
- Gently tap the components together with a rubber mallet until fully seated.
- Use a nail gun to secure the drawer bottom.
- Insert the drawer back into the grooves in the drawer sides.
- Tap into place with a rubber mallet and secure with a nail gun.
- Install the drawer locking devices onto the drawer front.
- Fully extend the drawer slides and lock the drawer box onto the slides.

Final Assembly

- Insert the door bumpers onto the face frame.
- Insert the shelf pins at the desired height.
- Place the shelf onto the shelf pins.
- Adjust the door and drawer as needed and verify smooth operation.

Base Full Height Door

Getting Ready

- Begin by laying out all parts on a clean, protected surface.
- Gather the tools and materials needed for assembly:
 - Wood glue
 - Rubber mallet
 - Screwdriver
 - Nail gun

Cabinet Assembly

- Screw the side panel brackets into the predrilled upper and lower holes on the face frame.
- Apply wood glue into the grooves on both sides and along the bottom of the face frame.
- Insert the first side panel into the groove and secure it to the side panel brackets.
- Repeat with the second side panel.
- Slide the bottom panel into the grooves in the side panels and face frame.
- Slide the back panel into the grooves in the side panels.
- Attach the corner brackets to the top of the side panels, face frame, and back panel.

Door Assembly

- Insert the hinges into the pre-bored holes in the door.
- Secure the hinges with the provided screws.
- Align the hinges with the face frame and attach the door to the cabinet.

Final Assembly

- Insert the door bumpers onto the face frame.
- Insert the shelf pins at the desired height.
- Place the shelf onto the shelf pins.
- Adjust the door as needed and verify smooth operation.

Wall Cabinet

Getting Ready

- Begin by laying out all parts on a clean, protected surface.
- Gather the tools and materials needed for assembly:
 - Wood glue
 - Rubber mallet
 - Screwdriver
 - Nail gun

Cabinet Assembly

- Screw the side panel brackets into the predrilled upper and lower holes on the face frame.
- Apply wood glue into the grooves on both sides and along the top and bottom of the face frame.
- Insert the first side panel into the groove and secure it to the side panel brackets.
- Repeat with the second side panel.
- Slide the bottom panel into the grooves in the side panels and face frame.
- Slide the top panel into the grooves in the side panels and face frame.
- Slide the back panel into the grooves in the side panels.
- Secure the top and bottom of the cabinet to the faceframe and backpanel using the supplied brackets
- Use a nail gun to secure the back panel to the side panels

Door Assembly

- Insert the hinges into the pre-bored holes in the door.
- Secure the hinges with the provided screws.
- Align the hinges with the face frame and attach the door to the cabinet.

Final Assembly

- Insert the door bumpers onto the face frame.
- Insert the shelf pins at the desired height.
- Place the shelf onto the shelf pins.
- Adjust the door as needed and verify smooth operation.

Diagonal Corner Wall Cabinet

Getting Ready

- Begin by laying out all parts on a clean, protected surface.
- Gather the tools and materials needed for assembly:
 - Wood glue
 - Rubber mallet
 - Screwdriver
 - Nail gun

Cabinet Assembly

- Screw the side panel brackets into the predrilled upper and lower holes on the face frame.
- Apply wood glue into the grooves on both sides and along the top and bottom of the face frame.
- Insert the first side panel into the groove and secure it to the side panel brackets.
- Repeat with the second side panel.
- Slide the bottom panel into the grooves in the side panels and face frame.
- Slide the top panel into the grooves in the side panels and face frame.
- Slide the back panels into the grooves in the side panels.
- Use a nail gun or the supplied brackets to secure the back panel to the side panels

Door Assembly

- Insert the hinges into the pre-bored holes in the door.
- Secure the hinges with the provided screws.
- Align the hinges with the face frame and attach the door to the cabinet.

Final Assembly

- Insert the door bumpers onto the face frame.
- Insert the shelf pins at the desired height.
- Place the shelf onto the shelf pins.
- Adjust the door as needed and verify smooth operation.