

Accessory Introduction (3-door Shoe Cabinet as An Example)



Assembly



1. Take out the side bracket and the support strips and install them with large screws.



2. Take out the other side bracket and attach with large screws.



3. Take out the top tier panel and install it with large screws.



4. Take out the door stopper and insert them into the holes.



5. Take out the smooth connector and insert it into the hole of the side bracket.



6. Take out the door panel and left and right plastic baffles and install them with small screws.



7. Take out the panel A and install it with small screws.



8. Take out the panel B and install it with small screws.



9. Take out the door handle and install it with flat head screws.



10. Then attach the door panel to the side bracket with large screws (large screws through the smooth connectors).



11. Peel off the double-sided adhesive tape and attach it to the anti-tipper (both back and front).



12. Then fix the anti-tipper to the wall as shown in the picture (keep the wall and the shoe cabinet clean before sticking).