







ASSEMBLY INSTRUCTIONS & PARTS IDENTIFICATION

UPHOLSTERED CHAIR

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

Hardware kit			
No		Description	Q'Ty
A		Lock Washer 5/16"	11 pcs
B		Flat Washer 5/16"	11 pcs
C		Long Bolt 1/4"x 3"	4 pcs
D		Medium Bolt 1/4"x 2"	4 pcs
E		Short Bolt 1/4"x 1.5"	3 pcs
F		Allen Key	1 pc

Key Parts			
No		Description	Q'Ty
1		Chair Back	1 pc
2		Complete Seat	1 pc
3		Front Legs	2 pcs
4		Floor glide	4 pcs

Remove bottom seat material before setup

FABRIC CARE INSTRUCTION REGULAR CARE

Clean with shampoo, foam, or dry cleaning solvents as desired.

Do not saturate with liquid. Pile fabrics may require brushing to restore appearance.

Cushion covers should not be removed and dry cleaned.

FABRIC CONTENT: 100% Polyester; Cleaning code "WS"

STEP 1

- Carefully lay Chair Back flat on a smooth flat surface to prevent scratches.

- Affix Complete Seat to Chair Back by inserting a Flat Washer (B), Lock Washer (A) with Short Bolt (E) into each of the hole on the back rail of the seat, and Long Bolt (C) with washes into each of 2 holes in the Complete Seat corners. (See Detail B & C).

- Tighten screws with provided Allen Key (F) by turning clockwise until secure.

STEP 2

- Carefully turn complete seat upside down and attach each Front Legs to the front corners of the Complete Seat with a Flat Washer (B), Lock Washer (A) and Medium Bolt (D). (See detail C). Keep tightening the bolts this point.

