

# Installation Manual

## List of accessories:



## Installation of hinge layer board



① Remove the hinge layer board and install the door stopper with small screws



② Flip the layer board, remove the hinges, and install them with small screws

## Door panel installation



① Remove the door panel and door mat and install them with small screws



② Remove the hinge and install it with a small screw

## Installation Tips

1. Strictly follow this assembly manual for operation
2. Carefully check whether the components inside the packaging box are complete and flawless
3. Clean the surface of the shoe cabinet only with a cloth or a slightly damp cloth, do not use strong scrubbing
4. The use of mismatched accessories may cause product damage. Please confirm the various accessory models before assembly





# Start assembly



Bottom layer groove facing upwards

① Take out the side bracket and install it with large screws on the bottom layer of the left side bracket (pay attention to aligning the grooves of the side bracket and the layer plate)



② Take out the ordinary board and install it with large screws



③ Take out the hinge layer board that has been installed with the hinges and door stopper, and install it with large screws



④ Take out the small layer board and install it with large screws



⑤ Take out 2 vertical bars and install them with large screws



⑥ Take out the small layer board and vertical bar and install them with large screws



⑦ Take out the side bracket and install it with a large screw on the right side



⑧ Take out the kicker bar and install it with medium screws



⑨ Take out the backboard, insert the Backguard bar A and B along the groove, and install the backguard bar A with large screws



⑩ Flip over the shelf, remove the top panel and install it with large screws



Take out 3 short vertical bars and install them with large screws



Take out the rear gear bar and install it with large screws



Take out the top door panel and install it with the hinge using small screws



Take out the door panel A with the hinges and fix it to the bracket with small screws for installation



Similarly, install another door panel and complete the installation!