

Solid Wood Executive Desk

Installation Instructions

Step 1: Pull out the drawer completely, install the baffle, align the holes on the baffle, and tighten with screws.



Step 2: Install the panel. Insert the panel directly into the slot. Align the holes from the inside of the cabinet and tighten with screws.

