

PEEL & STICK
WALLPAPER

INSTALLATION GUIDE

Professional Application for a Refined, Luxurious Finish

OVERVIEW

Peel and stick wallpaper offers a clean, modern solution for elevating interiors with minimal disruption. When installed correctly, it delivers a superior, high-end aesthetic comparable to traditional wallpapering—without glue or permanent commitment.

SURFACE REQUIREMENTS (CRITICAL)

For optimal adhesion and longevity:

SUITABLE SURFACES

- Smooth, flat walls
- Painted drywall with matte, eggshell, or satin finishes

UNSUITABLE SURFACES

- Textured walls (including orange peel, knockdown, or heavy stippling)
- Stone, glass, or high-gloss finishes (these reduce adhesive grip and can cause lifting or failure)
- Brick, concrete, unfinished wood, or porous surfaces

IMPORTANT:

The adhesive is engineered for controlled bonding on smooth, low-sheen finishes. Higher gloss levels create a barrier that weakens adhesion.

PREPARATION

1. CLEAN THE SURFACE

Remove dust, grease, and residue using a mild, non-abrasive cleaner. Allow the wall to dry completely.

2. CURE TIME FOR FRESH PAINT

Wait at least 2-4 weeks after painting before installation.

3. ENVIRONMENTAL CONDITIONS

Ideal temperature: 65°F-85°F (18°C-27°C). Avoid high humidity and moisture during installation.

4. TOOLS RECOMMENDED

- Measuring tape
- Level or laser level
- Utility knife (sharp blade)
- Sponges or lint-free cloth
- Marble floor cloth

PROFESSIONAL TIP

For a truly luxurious finish, lighting and alignment are everything—take extra care with your first panel. It sets the visual standard for the entire installation.

INSTALLATION STEPS

1. MEASURE & ALIGN

Begin on a vertical reference line—like a corner, door frame, or a plumb line.

2. PEEL BACKSLIP

Peel the top of the panel back by 12 inches to create a hinge.

3. APPLY WITH PRESSION

Press the exposed adhesive to the wall. Use a smoothing tool to eliminate air pockets. Work top to bottom, center to outside.

4. CONTINUE IN SECTIONS

Stagger vertical seams, leaving a 1/8" gap between panels. Avoid overlapping the material.

5. TRIM EXCESS

Use a sharp blade to trim any stray edges, baseboards, and corners.

6. SEAL SEAMS

Seal seams with a clear, non-toxic adhesive. Apply sparingly to the edges.

FINISHING TOUCHES

- Re-smooth all panels to ensure full adhesion.
- Inspect seams and edges for lifting.
- Allow 24 hours for adhesive to fully cure.

REMOVAL

Gently peel back a top corner at a 45° angle. Remove slowly to minimize surface impact. Residue is minimal when applied to proper surfaces.

DISCLAIMERS & IMPORTANT NOTES

SURFACE COMPATIBILITY

This product is not suitable for textured walls or surfaces with irregular finishes. Adhesive failure is likely under these conditions.

PAINT FRESH PAINT

Avoid applying to semi-gloss or glossy paints. An inked, surface finish can compromise adhesive performance.

SURFACE SENSITIVITY

Application on fragile, newly painted, or heat-sensitive paint may result in peeling or cracking during removal.

ENVIRONMENTAL FACTORS

Excess humidity, temperature fluctuations, or poor ventilation may affect adhesion and durability.

JOINT RESPONSIBILITY

It is strongly recommended to consult a professional installer for large-scale or complex installations.

WARRANTY LIMITATIONS

Warranty covers only defects in materials or workmanship. It does not cover damage caused by improper installation, environmental factors, or misuse.

THANK YOU FOR CHOOSING OUR PEEL & STICK WALLPAPER

ENJOY YOUR BEAUTIFULLY TRANSFORMED SPACE