



PERFECT SHUTTERS, inc.

The World's Largest Selection of Styles, Sizes, & Colors

www.perfectshutters.com

sales@perfectshutters.com

Installation Instructions Vinyl Shutter Spikes

WATCH OUR INSTALLATION VIDEO: <http://perfectshutters.com/product-support/installation-2/>

1. Lay the shutter face up on a clean, flat surface.
2. Measure 2 inches down from the top of the shutter and up from the bottom of the shutter and mark a spot in the center of the side rail. Mark each side rail at the center/center. (SEE FIGURE #1)
3. Drill a 5/16" inch diameter hole at each of the marks. (SEE FIGURE #1)
4. Position the shutter on the house next to the window. Using a suitable marker, mark the mounting hole locations on the building.
5. Remove the shutter and, where marked, drill a 5/16" inch diameter hole through the Wood, Vinyl or Aluminum siding only.
Do not drill into the wall
6. If the wall is Wood
 - Drill a 1/4" inch diameter hole, 2 1/4" deep into the wall.If the wall is Masonry or Brick
 - Drill a 1/4" inch diameter hole, 2 1/4" deep into the wall.***Note: A concrete anchor is not recommended when using shutter spikes***
7. Position the shutter on the house next to the window. Place shutter spikes in each pre-drilled hole.
8. Using a hammer, gently tap in each shutter spike, until all shutter spikes are started. Then finish tapping them all in.
BE CAREFUL NOT TO TAP THEM IN TOO FAR!
9. Repeat this process for all remaining shutters.

FIGURE #1

*** For the Warranty to Be In Force ***

The Shutter must be mounted with the shutter spikes in the positions specified in the illustration. The shutter spikes must go into the wall.

TOOLS REQUIRED

- Power Drill
- Phillips Head Screw Driver
- Tape Measure
- Pencil/Marker
- 1/4" Drill Bit
- 5/16" Drill Bit

