

Assembly Instructions



Put pressure on the bottom of the swivel plate and turn it 45 degrees as shown in picture



Place the bucket on top of Base lining up the 4 bolt holes



Install lock washer 1st with flat washer as shown

Put the bolts in head up
Bolt to the Bucket



Tighten all hardware

Put seat on Frame & use
Drill to connect screws