

<p>① threaded rod ② rope tube</p>	<p>⑧ fabric lampshade 6pcs</p>	<p>⑪ canopy 1pcs ⑫ cap nut 2pcs</p>	<p>1.Rotate the rod ① to remove out the rope tube ② and plate ③.</p>
<p>④ light arm 6pcs ⑤ lock nut & teeth lock washer ⑥ socket ring ⑥</p>	<p>⑨ long hanging tube 4pcs</p>	<p>⑬ tool 1pcs</p>	<p>2.Install the arms ④ to the plate ③ with lock nut & teeth lock washer ⑤, adjust the arm to suitable position like picture shown.</p>
<p>⑦ splicing connector 2pcs</p>	<p>⑩ short hanging tube 1pcs</p>	<p>⊗ X 1PCS ⊗ X 1PCS ⚡ X 3PCS ⚡ X 3PCS ⚡ X 3PCS</p>	

1.Pull the orange operating handle A to open the inlet hole, insert the wire B.
2.Press the operating handle A to finish wiring.
(Note: one inlet hole can put 2 or 3 wires inside)

3.Connect all the wires by parallel with connectors ⑦ (all live line-L use one connector, and neutral Line-N use another connector).
4.Install the rope tube ② to the light fixture with rod ①.

5.Let the wire of the fixture go through the tube ⑨ and tube ⑩, rotate to fasten all tubes to the fixture.(can connect more tubes to get the height you need)

Please operate with gloves to avoid leaving stains on the lampshade.

6.Install the canopy ⑪ to the fixture.
7.Use the tool ⑬ to install the fabric lampshade ⑧ to the fixture with socket ring ⑥.(Put the socket ring ⑥ in the tool ⑬ first, and rotate to fasten the lampshade ⑧ to the bulb holder)

8.Install the bracket to the ceiling junction box with screw ⑭.
9.Connect the wire to the home line with cap connector ⑮.
10.Install the fixture to the bracket with cap nut ⑫.
11.Install the bulb ⑯.

Please read carefully before installation!!!
Note : Please make sure that the electricity is powered off during installation !Only a professional electrician should install this kind of product !