

Installation Instructions

Interior Door Slabs

Installation Instructions

Thank you for selecting our products. Attached are recommended installation instructions for all types of wood Interior door slabs including molded door and MDF stile & rail door. Read these instructions thoroughly before beginning. They are designed to work in most existing applications however; existing conditions may require changes to these instructions. If changes are needed, they are made at the installer's risk. For installations other than indicated in these instructions, contact a building professional.

NEEDED MATERIALS AND TOOLS

NEEDED MATERIALS

NOTE! Follow all material manufacturers' instructions for proper use and compatibility.

- Hinges
- Wood screws: 3/4" minimum through hinges into the slab and frame; For MDF stile & rail door, 1 1/2 - 2 1/2" through each of the top two hinges into framing
- Wood putty/spackle
- Lockset and template
- Finishing supplies (See page 9 for details)
- Masking tape (for trimming)
- 150-280 grit sandpaper

NEEDED TOOLS

- Safety glasses
- Screwdrivers
- Pencil
- Chisel or router
- Drill with bits and hole saws
- Tape measure
- Level
- Finishing tools (See page 9 for details)
- Circular saw (for trimming)
- Wood plane (for trimming or beveling)
- Hammer
- Punch

SAFETY AND HANDLING

SAFETY

- Read and fully understand ALL manufacturers' instructions before beginning.
- Do not work alone. Two or more people are recommended. Use safe lifting techniques.
- Use caution when handling glass. Broken or cracked glass can cause serious injury.
- Wear protective gear (e.g. safety glasses, gloves, ear protection, etc.).
- Operate hand/power tools safely and follow manufacturer's operating instructions.

IF INJURY OCCURS, IMMEDIATELY SEEK MEDICAL ATTENTION!

MATERIALS AND SLAB HANDLING

- Allow doors to acclimate for at least 24 hours to local conditions before installation or finishing.
- Store slabs in a dry, well-ventilated protected area off of the floor. Buildings where humidity and temperature are controlled provide the best storage facilities (recommended conditions 30%-50% Relative Humidity and 50°F to 90°F)
- Protect from exposure to direct sunlight during storage.
- Handle doors with clean hands or while wearing clean gloves.
- Lift and carry doors to move, do not drag across one another.
- Heed material manufacturers' handling and application instructions.
- Install only into vertical walls and when conditions are dry.


1 REMOVE PACKAGING AND INSPECT SLAB

- Remove shipping materials such as corner covers, shipping blocks or pads.
- Inspect slab for cosmetic damage, squareness and warp
- Verify it is the correct product (size, color, design, handing etc.)

If any of the above conditions represent a concern, do not install the slab. Contact the supplier for recommendations.

2 INSPECT EXISTING JAMB

- Existing jamb should be 3/16" wider than the slab and at least 3/8" taller. There should be enough distance between the jamb edge and the stop to accommodate the thickness of the slab.
- Verify the existing jamb is square. The (A) and (B) measurements should be the same. Maximum allowable deviation from square is 1/4"
- Verify the existing jamb is level and plumb (C) and (D). The maximum allowable deviation is 1/8"
- The opening floor or sill must be flat and level (not be crowned or sagged) (D).
- The face of the rough opening must be in a single plane (E) with less than 1/8" twist from corner to corner.



Do not install the slab unless the jamb meets the above conditions. Professional assistance may be necessary to correct any problems before installation.

3 INSTALL SLAB


IMPORTANT: The door slab should be finished (e.g. painted) on all six sides with an equal number of coats after all routing, trimming, boring and touch-up has been completed and it has been properly fit in the jamb.

NOTE: If hinges are already installed on the slab, do not remove hinges for finishing.


Failure to finish on all six sides and install into a square, level and plumb condition could result in denial of warranty claims for operational or performance problems.

PREPARE JAMBS AND SLAB

1. Measure the existing jamb (not the stop) from floor to head and from side to side in several places to verify the slab will fit. The jamb should be 3/16" wider than the slab (1/16" clearance on the hinge jamb and 1/8" clearance on the strike jamb) and tall enough (usually 1/4" - 1/2" taller) to allow 1/8" clearance on the head jamb and allow the slab to operate without rubbing on any flooring.




2. If necessary to fit the existing jamb, a maximum of 1/4" can be trimmed from each side of hollow or solid core molded doors only. Trimming any other type is not recommend. For the best appearance, trim an equal amount from opposite sides. To minimize chipping, stick masking tape along the cut line to each face of the slab. Make the cuts with a fine toothed circular saw (height) and wood plane (width). Trimming beveled edges may require re-beveling.




PREPARE JAMBS AND SLAB - CONTINUED

3. The latch stile may have a pre-cut 2" or 3" bevel. This bevel maintains a 1/8" clearance between the jamb and latch edge and improve the fit when the slab is closed. If the latch stile is not beveled, and a bevel is preferred, use a wood plane or fine-toothed saw to cut a bevel so that the slab face that rests against the stop becomes slightly narrower than the opposite face.






TEST SLAB FIT IN JAMBS

Before installing any hardware, fit the slab in the frame and verify it will fit properly. Looking at the hinge side of the slab when it is closed, there should be 1/16" gap between the slab and hinge jamb and 1/8" between the slab and the head and strike jamb.



INSTALL HINGES


1. Three hinges are recommended for slabs up to 84" in height and four hinges for slabs over 84".
2. If re-using existing jambs, verify the existing hinge locations are plumb, or all in a straight line vertically. Position the new hinges in the existing locations and modify the mortises as necessary. Match the slab to the jambs using the following instructions.
3. If installing new jambs, measure down from the underside of the top of the jamb 7" to position the top of the top hinge. Measure up from the bottom of the slab 10" to position the bottom of the bottom hinge. Place the middle hinge halfway in between.
4. When marking the slab for hinges, make sure the measurement from the top of the slab to the top of the hinge route is 1/8" smaller than the distance from the head jamb to the top of the top hinge. This will allow 1/8" gap between the slab and head jamb.
5. When marking the slab, the distance from the inside face to the back of the hinge route should be 1/16" less than the depth of the hinge route on the jamb.
6. Using a template, mark the jambs and slab where the hinges will be mounted. Using a chisel or router, notch the jamb and slab for the outline of the hinge leaves and no deeper than the thickness of the leaves.
7. Using the hinge as a template, mark screw hole locations and drill pilot holes for all screws. If possible, it may be easier to remove the hinge pin to separate the hinge leaves. Use a hammer and a punch to drive the pin from the open end. Install the hinge leaves separately on the jambs and slab (we recommend using a hand screwdriver when installing screws into the slab to prevent stripping). Then, hang the slab in the frame by aligning the hinge leaves and re-install the hinge pins.



4 COMPLETE INSTALLATION


INSTALL LOCKSET AND FINISH INSTALLATION

1. The center of the hole for the lockset is usually 44" from the top of the slab and either 2 3/8" or 2 3/4" on center from the edge, depending on the latch. For slabs that have a rail (horizontal member) across the center of the slab, the lockset should be centered in this rail. Using the lockset manufacturer's instructions and template, drill for lockset. Generally, a 2 1/8" diameter hole is needed for the lockset. Drill a 1" latch hole through the edge of the slab into the center of the lock hole to accommodate the latch for the lock.



Some latches have a radius (rounded corners) or rectangular face plate that will require the slab edge to be chiseled for fit. Drill pilot holes for attachment screws. Other latches are round (contractor drive-in) and can be tapped into place with a hammer.

2. Close slab and check for proper operation. Adjust as necessary.
3. Finish all surfaces of the slab if not already done.
4. If installing a solid core or MDF stile & rail slab, install a #9 x 2 1/2" screw in the center hole (as shown) in the top two hinges (through the leaves toward the jamb).



5 INTERIOR DOOR CARE & FINISHING

INITIAL CARE

- Interior doors need to be acclimated to the environment where they will be installed. This process normally takes two days.
- Doors stored for more than a few days should have the top and bottom rails sealed with a pre-stain wood conditioner.
- Single (not pre-hung doors) should be laid flat on a dry, clean surface.
- Do not subject them to extreme or rapid changes in humidity or heat.
- Avoid finishing in high humidity conditions.

FINISHING

- No finishing process exists today that totally eliminates the transmission of water vapor or moisture into and out of wood doors. The key to proper finishing is to slow down the transmission process so the door performs within tolerances.
- All doors have six sides—not two, not four, but six—front, back, two edges, plus the most ignored and most vulnerable, the top and bottom. Failure to finish all six surfaces uniformly is the number one cause of door failures.
- Sanding is critical—the first rule to remember is the importance of field sanding all interior door products. Every interior door, regardless of manufacturer or style, requires some surface preparation before finishing. The key component of this surface preparation is thorough sanding to remove naturally occurring surface blemishes, handling marks, dirt, etc.
- Before finishing, lightly sand a primed molded door with 220-grit sandpaper. Blow off all dust, sand lightly between finish coats with 320-grit sandpaper. Remove sanding dust with tack cloth before applying your finish.

HOW TO PAINT AN INTERIOR DOOR

SUPPLIES REQUIRED

- High Quality Paint - Approx. 1 Quart (latex paint is OK.)
- High Quality, Synthetic Bristle Paint Brush
- Painter's Tape
- Sandpaper (220 & 320 Grit)
- Cotton Cloth
- Elastomeric or Polyurethane Caulk (To ensure that the door unit is properly caulked and all fastener holes are filled.)

STEPS

NOTE: All our interior door products are primed at the factory, follow the steps below to apply the paint.

Step #1

Ensure the door unit is properly caulked per installation instructions. If necessary, set and fill all fastener holes. Ensure all caulking is fully cured before proceeding to the next step.

Step #2

Remove or mask off all hardware prior to painting.

Step #3

Lightly scuff sand the door and jamb per above sanding instructions.

Step #4

Wipe the door with a clean cotton cloth.

Step #5

Apply 2 coats of a quality paint according to manufacturer's instructions. Paint the panels first then the stiles and rails. Allow the door to dry completely between coats.

NOTE: Make sure all six sides - front, back, edges, top and bottom - receive the same uniform overage.

Step #6

Allow the paint to dry completely before unmasking and installing hardware.