

USER GUIDE

SHOE RACK

Natural / Stylish / Unique

HARDWARE



! DOOR ASSEMBLY



1. Split off Hinge (n).

© 2020-2023 by Pundarika LLC - MoNiBloom.com



2. Secure Door (i) and Hinges (n) with Small Screws (r).

! HINGE ASSEMBLY



1. Secure Bottom Panel (h) and Hinges (n) with Small Screws (r).



2. Secure Panels (k) and Hinges (n) with Small Screws (r).

! ATTENTION

- ① Please always read and follow the assembly, maintenance and operating instruction.
- ② Do not discard any of the packaging until you have checked that you have all the parts and pack of fittings.
- ③ Keep children away during assembly. This item contains small parts which can be swallowed by children.
- ④ Wipe frames with water gently, do not use bleach, acid, or other solvents.
- ⑤ Check all hardware before assembly. Incorrect parts used may lead to damage.



Scan the QR code to view the assembly video.



FINISHED PRODUCT



ASSEMBLY INSTRUCTIONS

The assembly instructions may vary depending on the number of tiers.



- ① Connect Left Frame (a) and Right Frame (b) with Hinge installed Bottom Panel (h) as picture shown. Secure them with Large Screws (p). Keep the grooves of frames and panel aligned.



- ② Secure Back Slat (g) with Large Screw (p).



- ③ Position Hinge installed Panel (k) as picture shown. Secure them with Large Screws (p).



- ④ Secure Panels (j) with Large Screws (p) as picture shown.



- ⑤ Secure Top Panel (l) with Large Screws (p).



- ⑥ Turn around the frame. Install Back Panel (c) through the grooves of Back Slat (e) and the side frames.



- ⑦ Install Back Slat (g) and the rest Back Panels (c) through grooves.



- ⑧ Secure Top Slat (d) with Large Screws (p). Tighten Extra Screws (o) on top.

© 2020-2023 by Pundarika LLC - MoNiBloom.com



- ⑨ Turn around.



- ⑩ Secure Door (i) and Hinge (m) with Small Screws (r).



- ⑪ Repeat step 10 to install all other Doors (i).



- ⑫ Secure Bottom Slat (e) with Medium Screws (q).